

---

## Installation and Maintenance of Aqua Logic PVC Sumps

### Unpack your PVC Sump:

- Carefully remove the sump from the box or crate. NEVER lift the sump by reinforcement bars, filter bag holders, or side wall flanges to avoid personal injury or damage to the sump.
- ONLY Lift sump from the bottom, taking care not to drop or rest on an uneven surface.
- If sump includes an acrylic window, take care not to scratch or damage the window while moving the sump.
- Inspect the sump for possible shipping damage. If damaged please refer to the damage claims instructions on the shipping container.

### Placement of your PVC Sump:

- Place the PVC sump on a sturdy flat surface, free of debris, and rest entirely on its own base to avoid damage.
- If PVC sump came with a stainless steel stand or rack, find a level surface for each of the feet and level sump.
- Avoid setting stand feet in area that is constantly wet, where possible.
- Before filling, ensure enough space around sump for proposed plumbing or additional equipment, to avoid having to drain and move sump.
- DO NOT move sump with water in it. Empty before moving.
- DO NOT use sump outdoors. Placement outdoors will void limited warranty and can cause irreparable damage to sump.

### Continued care of you PVC Sump:

Your Aqua Logic PVC sump requires little maintenance but will benefit from the following:

- DO NOT stack sumps or place heavy items on top of sump or reinforcement bars.
- Wipe away dirt or salt build up on the exterior of the sump with a soft cloth, warm water, and a mild detergent if needed.
- Avoid using harsh chemicals in or on your Aqua Logic Sump. Do not use abrasive steel wool or scrubbing brushes on sump.
- Periodically rinse and wipe down Stainless steel rack (if you purchased this option) if using in saltwater application.

**Your Aqua Logic PVC Sump is now in place and ready for use!**